


Frigidaire

Factory Parts Catalog



Product No.	CPLES399ECA	CPLES399EC9
	37652366J53SA	37652366J53S9
Series	30" slide-in	30" slide-in
Color	stainless	stainless
Market	Canada	Canada
Wiring Diagram	318271978	318271978
Owner's Guide	318203825	318203825
Installation Instructions	318201611	318201611
Timer Guide	318204126	318204126

 **Electrolux**

Electrolux Major Appliances
North & Latin America
5855 TERRY FOX WAY
MISSISSAUGA, ONTARIO, CANADA L5V
3E4


Publication No.
5995533246
09/02/12
(EN/SERVICE/ECL)
377

**30-INCH SLIDE-IN
ELECTRIC RANGE**

Model No.
CPLES399E

Copyright © 2009 Electrolux Home Products, Inc.
All rights reserved.

BACKGUARD



LA20BG0050

BACKGUARD

Model Index: A CPLES399E (CPLES399EC9)
B CPLES399E (CPLES399ECA)


POS. NO	PART NO.		DESCRIPTION
16	318299102	A B	Console, assy., black
16*	5304447071	A B	Clip, console, (2)
17	318306900	A B	Bracket, bushing, (2)
19	318313832	A B	Control Panel Assembly, steel/glass, stainless/black, w/touch pad
19A	318224405	A B	Panel, control mtg.
20 #	316462841	A B	Controller, electronic, ES510X
20*	5304453707	A B	Screw, 8-18 X 1/2
35	318233720	A B	Retainer, control panel, black
36	318319301	A B	Knob, control, black, (4)
42	318298001	A B	Trim, vent, black, upper
54 #	316441800	A B	Control, electronic, single element, (2)
54A#	316441801	A B	Control, electronic, dual element, (3), w/potentiometer
54B#	316441804	A B	Control, electronic, left front, dual element, w/potentiometer
55	316247700	A B	Nut, mounting
55A	316247800	A B	Washer, lock, mtg
69	5303323134	A B	Screw, 8-32 x 3/16, (4)
99 #	316435703	A B	Board, power supply
99A	318223900	A B	Gasket, dark grey
101	318233400	A B	Bushing, retainer
* #	318228859	A B	Harness, wiring, main, backguard
* #	318224849	A B	Harness, wiring, timer
*	08016432	A B	Screw, truss head, 8-18 x 0.375
*	5303300265	A B	Screw, 8-18 X 1/2, (4)
*	5303311333	A B	Screw, 8-32 x 3/8

BODY

Model Index: A CPLES399E (CPLES399EC9)
B CPLES399E (CPLES399ECA)

POS. NO	PART NO.		DESCRIPTION
1	318259220	A B	Back, main
1A	318225110	A B	Panel, main back, upper
2	318258902	A B	Shield, insulation, upper
3	318225210	A B	Panel, bodyside, upper RH
3A	318225211	A B	Panel, bodyside, upper LH
5	318175508	A B	Screw, leveling
6	318345214	A B	Rack, oven, (3)
8	318262001	A B	Cover, element
8A	318318600	A B	Bracket, element, hidden bake
9	316081900	A B	Pan, broilerOPTIONAL ACCESSORY
10	316082000	A B	Insert, broiler panOPTIONAL ACCESSORY
12	316445501	A B	Switch, oven light, door frame
* #	318231869	A B	Harness, wiring, door switch
14	318224000	A B	Receptacle, oven light
15	5303013071	A B	Bulb/Lamp, light
16	318406100	A B	Lens, oven light, glass
17	5304400195	A B	Retainer, light cover
29	316517600	A B	Spacer, oven door
37 #	316217002	A B	Probe, oven temp
39 #	318113111	A B	Cord, electric
41	5303310526	A -	Cover, hinge cutout
54	318222400	A B	Housing, oven light
58A	318386100	A B	Insulation, oven wrapper
58B	318133791	A B	Insulation, oven back, back/bottom
59	318072560	A B	Duct, oven vent
59A	318261600	A B	Bracket, vent tube
62	5303935061	A B	Terminal Block Kit
62*	5303323139	A B	Screw, 10-24 x 0.906
66 #	318255600	A B	Element, broil, 2750W
67 #	318254906	A B	Element, bake, 3400W, 8 pass
68	5304403015	A B	Support, hanger, (4), broil element
70	318259100	A B	Shield, insulation, sides, (2)
71	318260007	A B	Panel, rear box
76	318056217	A -	Front, oven
76	318056292	- B	Front, oven
80	5303320846	A B	Plate, oven mtg
81	318192400	A B	Spring, oven
82	318258708	A B	Shield, insulation, lower
83	318261400	A B	Liner, oven assy
86	318328010	A -	Receptacle, hinge
86	318561100	- B	Receptacle, hinge, (2)
86*	5304461333	- B	Screw, 10-32 x 17/32
87	318260605	A B	Bracket, cable mtg.
89 #	318261215	A B	Motor, latch assy
90	318296904	A B	Panel, filler, black, RH
90A	318296905	A B	Panel, filler, black, LH
107	318219405	A B	Cover, fan
108#	318073028	A B	Motor, blower
108A	318251300	A B	Bracket, fan support

BODY





BODY

Model Index: A CPLES399E (CPLES399EC9)
B CPLES399E (CPLES399ECA)

POS. NO	PART NO.		DESCRIPTION
109	318398300	A B	Fan Blade
111	318399800	A B	Nut, fan retainer
119#	318004900	A B	Switch, thermal
125#	5304463302	A B	Motor-convection
125*	318142100	A B	Washer, motor, convection
127	318317100	A B	Adapter Assembly, vent tube, w/converter
131	318272901	A B	Box, vent
132	318003000	A B	Plate, shield
161#	318255503	A B	Element, convection, 350 W
166	318298410	A B	Bracket, base support, (2)
166A	318298403	A B	Bracket, base support, lower, (2)
170	318335500	A B	Anti-tip & accessories
185	318165800	A B	Spacer
200	318298221	A B	Frame, drawer, front
201	318298210	A B	Frame, drawer
219#	318003634	A B	Thermostat, safety
272	318249403	A B	Tube, protector
* #	318224998	A B	Harness, wiring, main
*	3051050	A B	Screw, shoulder
*	3201861	A B	Screw, 6 x 0.375, (4)
*	08016432	A B	Screw, truss head, 8-18 x 0.375
*	5303211311	A B	Screw, 8 x 0.500
*	5303307980	A B	Screw, 8-32 x 0.437, (8)
*	5303323129	A B	Screw, 8 X 0.750
*	5304415832	A B	Screw, 8-18 x 0.406
*	5304436875	A B	Screw, 8-18 X 1/2, black

TOP/DRAWER




TPLES399ECH

TOP/DRAWER

Model Index: A CPLES399E (CPLES399EC9)
B CPLES399E (CPLES399ECA)

POS. NO	PART NO.		DESCRIPTION
1	318304401	A B	Drawer, body assembly
1A	318300002	A B	Panel, warmer drawer, side, (2)
1C	318300301	A B	Panel, warmer drawer, rear
2	318303901	A B	Panel, drawer, black, inner
4	318298825	A B	Panel, drawer, stainless, front
13	318259507	A B	Glide, warmer, inner RH
13A	318259506	A B	Glide, warmer, inner LH
15 #	318198830	A B	Element, surface, 6", 1200 W, (2)
15A#	318258203	A B	Element, bridge, 1800/2600
15B#	318198934	A B	Element, surface, 6/9, 1700/2700W, dual radiant
16	318223647	A B	Main Top, glass assy., black
29	318147430	A B	Bumper, (2)
39	316246100	A B	Handle, door/drawer, stainless
46	318225429	A B	Box, burner
51 #	318044827	A B	Light, indicator, clear
52	318122006	A B	Spring, element mtg, small
52A	318122008	A B	Spring, element mtg, 1800W/3000W
52B	318122011	A B	Spring, element mtg, 1200W/1800W
60	5303308458	A B	Screw, 10-24, (4)
81 #	318255301	A B	Element, warmer drawer
84 #	318005108	A B	Thermostat
85	318345601	A B	Rack, warmer drawer
86	316095800	A B	Clip, hold down, warmer element
87	318300102	A B	Panel, warmer drawer, lower
90	318368001	A B	Channel, glass protector, (2)
95	318303800	A B	Shield, wire
124	316105501	A B	Glide, outer/RH & LH, (2)
141#	318003634	A B	Thermostat, safety
165	318227503	A B	Plate, mounting
* #	318228930	A B	Harness, wiring, cooktop
* #	318231848	A B	Harness, wiring, pilot light
*	318531701	A B	Spacer, (2)
*	08016432	A B	Screw, truss head, 8-18 x 0.375
*	5303211311	A B	Screw, 8 x 0.500
*	5303300265	A B	Screw, 8-18 X 1/2, (4)
*	5303311333	A B	Screw, 8-32 x 3/8

DOOR




DOOR


Model Index: **A** CPLES399E (CPLES399EC9)
 B CPLES399E (CPLES399ECA)

POS. NO	PART NO.		DESCRIPTION
3A	318260401	A B	Trim, oven door, side, (2)
3B	318262101	A B	Cover, rear door, black, (2)
6	318260522	A B	Baffle, door
7	318372000	A B	Insulation, door, (2)
7A	318372002	A B	Insulation, door, (2)
8	316117500	A B	Glass, oven door, heat barrier
9	318259605	A -	Liner, door
9	318360108	- B	Liner, oven door
10	5303311174	A B	Screw, 10-24 x 3/8
12	318053130	A B	Seal, oven door, lower
13	318272189	A B	Door Assy, w/hameplate, stainless steel, outer, w/tape & foil
16	318212210	A B	Glass, oven door, heat barrier, lower door
17	318264710	A B	Spacer, glass, lower, (2)
23	318024747	A -	Hinge, door, lower, (2)
23	316456304	- B	Hinge, oven door, (2)
24	318260301	A B	Trim, door, black, lower
39	316246100	A B	Handle, door/drawer, stainless
40	318242702	A B	Bracket, glass holder, door, (2)
41	318370600	A B	Bracket, glass retainer, (2)
42	318382301	A B	Bracket, glass retainer, (4)
56	5304436875	A B	Screw, 8-18 X 1/2, black
64	318165800	A B	Spacer
*	5304415832	A B	Screw, 8-18 x 0.406

WIRING DIAGRAM



WIRING DIAGRAM



318271978 REV:A
SHEET/FEUILLE: 2/2