



- NOTE:
- | | | | |
|-------------|---------------------|-----------|----------|
| (CONDITION) | OL:OVEN LED | OG:ORANGE | BR:BROWN |
| DOOR:CLOSED | FM:FAN MOTOR | YW:YELLOW | WH:WHITE |
| COOK:OFF | TM:TURNABLE MOTOR | RD:RED | BK:BLACK |
| | SM:STIRRER MOTOR | BL:BLUE | GY:GREY |
| | CL:COOKTOP LED | GN:GREEN | PK:PINK |
| | CM:CONVECTION MOTOR | | |
| | DM:DAMPER MOTOR | | |