


# Microwaves

FFCM1134L W/B

## Countertop



### Product Dimensions

Height	12"
Width	20-3/8"
Depth	14-3/4"

### More Easy-To-Use Features

#### Effortless™ Reheat

Reheat almost anything at the touch of a button.

#### Multi-Stage Cooking

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

#### 10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

#### Control Lock Option

#### Electronic Clock/Timer

Helps you keep track of cook times.


#### Interior Light

Illuminates the contents of the microwave for increased visibility.

#### Large Glass Turntable

Even large items fit on our large glass turntable.

Available in:



## Signature Features

### Easy-Set™ Start

Quickly start cooking - one to six minutes - with just one touch.

### Ready-Select™ Controls

Easily select options with the touch of a button.


### Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

### Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

Features	
Control/ Timing System	Ready-Select™
Exterior Door Finish	Color-Coordinated
Handle Design	Push Button
Microwave Features	
Microwave Capacity (Cu.Ft.)	1.1
Watts (IEC-705 Test Procedure)	1,100
Interior Light	Yes
Interior Color	White
Turntable Diameter	11-1/4"
Turntable On/Off	
Control Lock	Yes
Clock	Yes
Touch Pad Buttons	23
Power Levels	10
Accessory Metal Rack	
Microwave Control Options	
Easy-Set™ Start	Yes
Popcorn Button	Yes
Chicken Nugget Button	
Baked Potato Button	Yes
Sensor Reheat Button	
Snack Button	
Beverage	Yes
Melt & Soften Options	
Auto Reheat Options	4
Snack Menu Options	
Auto Cook Options	5
Auto Defrost Options	Yes
Keep Warm	
Add-30-Seconds	Yes
Sensor Cooking Options	
Vegetable Cook Sensor	
Delay Start	
User Preferences	
Power Ratings	
Frequency (Mhz)	2,450
Watts @ 120 Volts	1,500
Amps @ 120 Volts	14
Specifications	
Oven Interior Height	9-11/16"
Oven Interior Width	14-15/16"
Oven Interior Depth	14-1/8"
Power Supply Connection Location	Rear
Voltage Rating	120V / 60Hz / 15A
Minimum Circuit Required (Amps)	13.5
Shipping Weight (Approx.)	32



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at [frigidaire.com](http://frigidaire.com).



Product Dimensions <sup>1</sup>	
A - Height	12"
B - Width	20-3/8"
C - Depth	14-3/4"

<sup>1</sup>A minimum clearance of 3 inches is required between microwave oven and adjacent walls. Leave a minimum clearance of 12 inches above microwave oven.

Accessories information available on the web at [frigidaire.com](http://frigidaire.com)

FRIGIDAIRE

USA • 10200 David Taylor Drive • Charlotte, NC 28262 • 1-800-FRIGIDAIRE • [frigidaire.com](http://frigidaire.com)  
 CANADA • 5855 Terry Fox Way • Mississauga, ON L5V 3E4 • 1-800-265-8352 • [frigidaire.ca](http://frigidaire.ca)

FFCM1134L 08/10

© 2010 Electrolux Home Products, Inc.

Specifications subject to change.  
 Printed in the U.S.A.